


# 24/50 P1



Rep.	Référence	Désignation
101	12B02186	Vis
102	12B02441	Deflecteur
103	12B02253	Tête
104	12B02188	Joint
105	12B00296	Ressort
106	12B02189	Amortisseur
107	12B00321	Joint
108	12B02190	Valve
109	12B00323	Joint
110	12B00310	Bague
111	12B02191	Bague
112	12B02500	Joint
113	12B02254	Piston
114	12B02193	Cylindre
115	12B00869	Joint
117	12B02195	Bague
118	12B00874	Joint
119	12B02503	Amortisseur
120	12B02451	Guide
121	12B00205	Vis
123	12B02452	Rondelle
201	12B00556	Joint
202	12B00532	Corps de servo-cmd
203	12B00213	Joint
204	12B00212	Joint
205	12B00502	servo-cmd
206	12B00565	Joint
207	12B00534	Ressort
208	12B00561	Joint
209	12B00533	Tige de servo cmd
210	12B00531	Couvercle
211	12B00496	Goupille
212	12B00535	Couvercle
213	12B00557	Joint
214	12B00209	Joint
215	12B01876	Goupille
216	12B00552	Goupille
217	12B02197	Gâchette
218	12B02198	Goupille
301	12B02255	Corps
302	12B01966	Joint

Rep.	Référence	Désignation
303	12B01919	Couvercle
304	12B00846	Bouchon
305	T023901	Raccord
401	12B00840	Joint
402	12B02456	Pied de cylindre
403	12B02202	Vis
404	12B01152	Vis
405	12B02257	Plaque de guidage
406	12B02463	Toquet
407	12B02464	Goupille
408	12B02258	Plaque avant
409	12B02259	Goupille
410	12B00096	Anneau de retenu
411	12B02471	Plaque avant
412	12B02260	Sécurité B
413	12B02261	Sécurité A
414	12B00206	Rondelle
415	12B02209	Vis
416	12B00164	Ressort
417	12B02210	Guide
418	12B02479	Poussoir
419	12B01020	Ressort
420	12B00221	Vis
421	12B01068	Vis
422	12B02262	Magasin
423	12B01736	Vis
424	12B02486	Entretoise
425	12B00937	Ressort
426	12B02488	Loquet
427	12B02490	Ecrou
428	12B00564	Rondelle
429	12B01643	Ressort
430	12B02263	Protection
431	12B02293	Protection
432	12B02355	Support
433	12B02362	Vis
434	12B02485	Couvercle
435	12B00567	Ecrou
436	12B01177	Vis
437	12B01086	Anneau de retenu
438	12B00947	Goupille