

RB398S(CE)


EXPLODED
VIEW AND SPARE
PARTS LIST

EINZELTEILDAR-
STELLUNG UND
ERSATZTEILLISTE

SCHEMA ECLATE ET
LISTE DES PIÉCES
DE RECHANGE

ESPLOSO DEI
COMPONENTI ED
ELENCO DELLE
PARTI DI RICAMBIO

DESPIECE DE LA
MAQUINA Y LISTA
DE RECAMBIOS



INDEX	CODE	DESCRIPTION
1	BB40112	BOLT 3X6
2	BB86701	TORX BOLT 3X5
3	RB70404	ARM B UNIT(397)
4	RB11999	WIRE GUIDE B(397)
5	RB12000	CUTTER
6	JJ10109	E-RING 2
7	RB12090	CUTTER LEVER B(397)
8	JJ10514	E-RING 3 CF
9	RB12005	CUTTER LEVER A(397)
10	FF51647	PIN 1647
11	RB12710	SHAFT
12	RB12004	CONNECTING ROD(397)
13	RB12780	PIN
14	RB11998	WIRE GUIDE A(397)
15	RB12121	FIXED CUTTER (N)
16	RB70493	CUTTER PLATE UNIT
17	RB12781	PLATE
18	RB81304	ARM A UNIT
19	RB11997	LEAF SPRING(397)
20	AA25113	PAN-HEAD SCREW 2X4
21	RB70741	ARM ASSY(398S)
22	KK33413	SPRING 3413
23	BB40839	HEX SOCKET HEAD CAP SCREW M46X16 MEC
24	RB12007	PIPE SPONGE
26	JJ10101	E-RING 4
27	RB81136	PIPE ASSY
28	RB70565	CURL GUIDE UNIT (399A)
29	RB12010	CURL GUIDE COVER
30	KK33365	TORSION SPRING
31	RB12110	STOPPER SHAFT WAS=RB11708
32	RB70567	CURL GUIDE ASSY(399A)
33	RB11816	HOOK
34	RB81113	WS PIN 2.5X10
35	RB12014	KEY
36	RB12017	SLEEVE A
37	RB12279	SLEEVE GUIDE
38	RB70675	TIP AXIS B
39	FF31599	PIN 1599
40	KK23730	COMP. SPRING 3730
41	RB12708	TIP AXIS A
42	RB12015	SLEEVE B
43	RB12789	CUTTER RING
44	RB12091	CUTTER RING GUIDE
45	JJ21011	C-RING 14
46	RB81314	TIP AXIS ASSY
47	RB12020	SPRING COLLAR
48	KK29026	COMP. SPRING 9026
49	RB12019	BUMPER
51	JJ21603	C-RING 20
52	RB10338	INTERNAL GEAR
53	RB12783	RING
54	RB70745	PLANET CAGE UNIT
55	FF31589	PIN 1589
56	RB10341	PLANET GEAR

57	RB10484	GEAR PRESS WHEEL
58	RB70736	SUN GEAR UNIT
59	RB70734	TWISTING MOTOR
60	EE31131	PLATE WASHER 1-3 CF
61	FF51817	HOLLOW PIN 1817
62	BB40810	BOLT 3X16
63	RB70710	SENSOR CURCUIT BOARD F UNIT
64	RB81347	REEL GUIDE ASSY
65	AA09501	KNURLED TIGHT 3X6 CF
66	FF51710	HOLLOW PIN 1710
67	BB41706	BOLT 4X10
68	FF31563	PIN 1563
69	KK34089	SPRING 4089
70	RB70719	RATCHET COVER ASSY
71	BB40720	BOLT 3X12
72	RB12791	SPECIFICATION LABEL
73	RB70705	MOTOR COVER ASSY (398S)
74	FF41871	STEP PIN 11871
75	KK34067	TORSION SPRING 4067
76	EE39609	RUBBER WASHER 1.8X6X2
77	BB40714	BOLT 3X50
78	RB12031	JOINT
79	AA21419	SCREW 3X8
80	RB81305	REEL HOLDER ASSY
81		
82	RB12038	REEL STOPPER SPRING
83	EE39184	PLATE WASHER 3.1X11.8X1
84	RB12035	REEL STOPPER
85	FF21240	PIN 2.5X6
86	RB12036	STOPPER PLATE
87	RB70427	REEL STOPPER ASSY
88	RB70770	REEL MAGAZINE ASSY
89	RB12772	PLATE B
90	BB41707	BOLT 4X16
91	EE11103	SPRING WASHER 2-4
92	EE39825	WASHER 4.5X7.4X0.8
93	KK24175	COMP. SPRING 4175
94	JJ10113	E-RING 2.5
95	RB10359	FEEDING GEAR B2
96	RB10362	RELEASE LEVER
97	FF41809	STEP PIN 1809
98	RB12852	HOLLOW PIN
99	EE32104	WASHER 2-3
100	RB10357	FEEDING GEAR B1
102	RB12766	WIRE GUIDE C
103	CC41104	HEX.NUT 1-3
104	RB12761	PARTITION PLATE
105	RB12765	PARTITION SPONGE
106	EE31133	WASHER 3.5X9X0.5
107	RB70509	FEEDING GEAR A ASSY
108	RB70729	FEEDING MOTOR ASSY
109	RB81312	FEEDING ASSY
110	RB10368	JAW A
111	KK33249	TORSION SPRING 3249
112	RB10370	JAW BASE

113	FF41822	STEP PIN 1822
114	RB10369	JAW B
115	RB70495	JAW BASE ASSY
116	RB12769	ROTARY PIN
117	RB81308	SOLONOID ASSY
118	FF41876	STEP PIN 1876
120	FF52119	HOLLOW PIN 2119
121	RB12029	ROTARY PLATE
122	FF21620	PIN 2X12
123	RB70771	BRAKE ASSY
124	BB40712	BOLT 4X8
125	RB12770	REEL PRESS
126	KK33373	SPRING 3373
127	AA22522	SCREW 3X8
128	ZS00034	MAIN SWITCH (441)
129	RB12796	LABEL TORQUE DIAL
130	RB12814	HARNESS COVER
131	RB70750	SWITCH BASE ASSY
132	RB12054	STEP PIN
133	RB12053	RELEASE STOPPER
134	RB12055	STOPPER BASE
135	RB12056	SPONGE F
136	RB81139	STOPPER BASE ASSY
137	KK29133	COMPRESSION SPRING 9133
138	BB40710	BOLT 3X8
140	BB40709	BOLT 3X16
141	RB12771	PLATE A
142	CC42512	HEX NUT 1A M4
143	RB12521	NOTICE LABEL
144	FF51714	HOLLOW PIN 1714
145	RB12745	REEL PROTECTOR
146	BB41503	BOLT 3X8
147	RB11979	COVER L(397)
148	RB81350	FRAME L ASSY(398S)
149	RB11987	WINDOW
150	RB12826	CONNECTOR BASE
151	RB12827	CONNECTOR COVER
152	AA05572	SCREW 3X8
153	RB12080	TRIGGER (397)
154	KK23656	COMPRESSION SPRING 3656
155	RB12101	TRIGGER LOCK LEVER(397)
156	RB81349	SWITCH HARNESS UNIT
159	RB12744	SWITCH BLOCK
160	RB81341	MAIN CIRCUIT BOARD UNIT
161	KK23604	COMPRESSION SPRING 3604
162	RB12813	FRONT HARNESS COVER
163	RB70697	ELECTRODE UNIT
165	RB11981	COVER R (397)
166	RB12689	WARNING LABEL
167	RB11985	USAGE LABEL
169	RB12742	398S LABEL
171	RB70706	FRAME R ASSY(398S)
173	RB81184	BELT HOOK ASSY
174	RB12752	LED COVER
176	RB12661	BRAND PLATE